


# 1. Histogram of an Image

1. Two images, *race.tif* and *kids.tif*, and their labeled histograms




*Figure 1: race.tif*



*Figure 2: Histogram of race.tif*



*Figure 3: kids.tif*



*Figure 4: Histogram of kids.tif*

## 2. Histogram Equalization

1. Function *equalize()*:

```
def equalize(X):
    L = 256
    m, n = np.shape(X)
    shape = (m, n)
    Z = np.zeros(shape)
    Fx_hat = np.zeros((1,256))

    h = np.histogram(X,bins=np.linspace(0,255,256))

    Fx_hat = np.cumsum(h[0])/np.sum(h[0])

    Ymax = np.max(Fx_hat)
    Ymin = np.min(Fx_hat)

    for i in range(m):
        for j in range(n):
            Z[i,j] = (L - 1)*((Fx_hat[X[i,j]+1] - Ymin)/(Ymax - Ymin))

    return Z, Fx_hat
```

Figure 5: *equalize()* Function

2. Labeled plot of  $\hat{F}_x(i)$  for the image *kids.tif*






Figure 6:  $\hat{F}_x(i)$  Plot for *kids.tif*

3. Labeled plot of the equalized image's histogram



*Figure 7: Equalized kids.tif Histogram*

4. Equalized image



*Figure 8: Equalized kids.tif Image*

### 3. Contrast Stretching

1. Function *stretch()*:

```
def stretch(X, T1, T2):  
    m, n = np.shape(X)  
    shape = (m,n)  
    output = np.zeros(shape)  
  
    for i in range(m):  
        for j in range(n):  
            if X[i,j] > T1:  
                if X[i,j] < T2:  
                    # output/X = rise/run --> output = rise/run * X  
                    output[i,j] = (255/(T2-T1))*(X[i,j] - T1)  
                else:  
                    output[i,j] = 255  
            else:  
                output[i,j] = 0  
  
    return output
```

Figure 9: *stretch()* Function

2. Transformed image and its histogram





Figure 10: Transformed kids.tif Image



*Figure 11: Transformed kids.tif Histogram*

## 4. Gamma ( $\gamma$ )

### 1. Setting the Black Level and Picture of Your Monitor

\* No Deliverables \*

### 2. Determining the Gamma of Your Computer Monitor

#### a. Image corresponding to the matching gray level




Figure 12: Image Corresponding to Matching Gray Level,  $g = 184$

#### b. Derivation of the expression which relates the matching gray level to the value of gamma

$$I_c = \frac{(I_{255} + 0)}{2}; I_g = I_{255} \left( \frac{g}{255} \right)^\gamma$$

$$\text{Find } \gamma: I_g = I_c$$

$$I_{255} \left( \frac{g}{255} \right)^\gamma = \frac{(I_{255} + 0)}{2}$$

$$I_{255} \left( \frac{g}{255} \right)^\gamma = \frac{I_{255}}{2}$$

$$\left( \frac{g}{255} \right)^\gamma = \frac{1}{2}$$

$$\log \left( \left( \frac{g}{255} \right)^\gamma \right) = \log \left( \frac{1}{2} \right)$$

$$\gamma \log \left( \frac{g}{255} \right) = \log \left( \frac{1}{2} \right)$$

$$\gamma = \frac{\log \left( \frac{1}{2} \right)}{\log \left( \frac{g}{255} \right)} = \frac{\log(1) - \log(2)}{\log(g) - \log(255)} = \frac{-\log(2)}{\log(g) - \log(255)}$$

- c. Values of the measured gray level and the measured gamma

$$g = 184$$

$$\gamma = \frac{-\log(2)}{\log(g) - \log(255)} = \frac{-\log(2)}{\log(184) - \log(255)} = 2.124$$

Measured Gray Level	Measured Gamma ( $\gamma$ ) Value
184	2.124

3. Gamma Correction

- a. Original and corrected images, with value of gamma used indicated in title



Figure 13: Original linear.tif Image




Figure 14: Gamma Corrected linear.tif Image,  $\gamma = 2.12$

- b. Formula used to transform the original image

$$x = 255 \left( \frac{y}{255} \right)^{\frac{1}{\gamma}}$$



- c. Corrected image, properly labeled



Figure 15: Original gamma15.tif Image




Figure 16: Corrected gamma15.tif Image

- d. Procedure used to change the gamma correction of the original image
- i. Transform pixel data back to un-corrected gamma state: Calculate  $y_1$  from  $x_1$ , where  $x_1$  is the input data of image *gamma15.tif* and  $\gamma_1$  is the current gamma correction of the image

$$y_1 = 255 \left( \frac{x_1}{255} \right)^{\gamma_1}$$

- i. Re-correct for desired gamma value: calculate  $x_2$  from  $y_1$ , where  $\gamma_2$  is the gamma correction value for the monitor being used

$$x_2 = 255 \left( \frac{y_1}{255} \right)^{\frac{1}{\gamma_2}} = 255 \left( \frac{255 \left( \frac{x_1}{255} \right)^{\gamma_1}}{255} \right)^{\frac{1}{\gamma_2}} = 255 \left( \frac{x_1}{255} \right)^{\frac{\gamma_1}{\gamma_2}}$$

Solution: Apply a gamma correction of  $\gamma = \frac{\gamma_1}{\gamma_2} = \frac{1.5}{2.12}$  to the original data from *gamma15.tif*